

# STOP FS

## Stopflex hose clamp

### Properties

|                    |   |
|--------------------|---|
| <b>Application</b> | Personal protection against whipping hose |
| <b>Inner layer</b> | Steel and rubber                          |
| <b>Surface</b>     | electro galvanised                        |



### Description

High tensile steel clip with rubber insert for fitting on the hose.

### Item

| Identification  | Clamping range (mm) | Fixing bolt |
|-----------------|---------------------|-------------|
| STOP FS 11 11.5 | 11 - 11,9           | M 6         |
| STOP FS 12 12.5 | 12 - 12,9           | M 6         |
| STOP FS 13 13.5 | 13 - 13,9           | M 6         |
| STOP FS 14 15   | 14 - 15,5           | M 6         |
| STOP FS 16 17   | 16 - 17,9           | M 6         |
| STOP FS 17 18   | 17 - 18,9           | M 6         |
| STOP FS 18 19   | 18 - 19,9           | M 6         |
| STOP FS 20 21   | 20 - 21,9           | M 6         |
| STOP FS 21 22   | 21 - 22,9           | M 6         |
| STOP FS 22 23   | 22 - 23,9           | M 6         |
| STOP FS 24 25   | 24 - 25,9           | M 6         |
| STOP FS 25 26   | 25 - 26,9           | M 6         |
| STOP FS 26 27   | 26 - 27,9           | M 6         |
| STOP FS 27 28   | 27 - 28,9           | M 6         |
| STOP FS 28 29   | 28 - 29,9           | M 6         |
| STOP FS 30 31   | 30 - 31,9           | M 6         |
| STOP FS 32 33   | 32 - 33,9           | M 6         |
| STOP FS 34 35   | 34 - 35,9           | M 6         |
| STOP FS 36 37   | 36 - 37,9           | M 6         |
| STOP FS 38 39   | 38 - 39,9           | M 6         |
| STOP FS 39 40   | 39 - 40,9           | M 6         |
| STOP FS 40 41   | 40 - 41,9           | M 6         |
| STOP FS 42 43   | 42 - 43,9           | M 6         |
| STOP FS 43 44   | 43 - 44,9           | M 6         |
| STOP FS 44 45   | 44 - 45,9           | M 6         |
| STOP FS 45 47   | 45 - 47,9           | M 8         |
| STOP FS 48 50   | 48 - 50,9           | M 8         |
| STOP FS 51 53   | 51 - 53,9           | M 8         |
| STOP FS 53 54   | 53 - 54,9           | M 8         |
| STOP FS 54 56   | 54 - 56,9           | M 8         |
| STOP FS 57 59   | 57 - 59,9           | M 8         |
| STOP FS 60 62   | 60 - 62,9           | M 8         |
| STOP FS 63 65   | 63 - 65,9           | M 8         |
| STOP FS 66 68   | 66 - 68,9           | M 8         |
| STOP FS 69 71   | 69 - 71,9           | M 8         |
| STOP FS 72 74   | 72 - 74,9           | M 8         |
| STOP FS 75 77   | 75 - 77,9           | M 8         |
| STOP FS 78 80   | 78 - 80,9           | M 8         |
| STOP FS 81 83   | 81 - 83,9           | M 8         |
| STOP FS 84 86   | 84 - 86,9           | M 8         |
| STOP FS 87 89   | 87 - 89,9           | M 8         |
| STOP FS 90 92   | 90 - 92,9           | M 8         |
| STOP FS 93 95   | 93 - 95,6           | M 8         |