PRESSE UPS

Low-pressure hose press



Note

Before use, mount the press on a suitable base (workbench) with four screws.

Description

The UPS press can be used to produce all low-pressure hose lines with nominal widths of 3 to 16 mm.

Item
Identification
PRESSE UPS 1

Despite careful checking, we cannot guarantee the accuracy of all information included on this site, and we accept no liability.