


HK IHV REPKIT

Repair kit for bladder accumulator



Note

Repairs to pressure accumulators may only be carried out by qualified personnel! Please observe the repair instructions supplied.

Description

For IHV bladder accumulators

Consisting of replacement bladder, seal kit and split ring

Item

| Identification | for bladder accumulator | Replacement bladder | Weight (kg) |
|--------------------|-------------------------|--|-------------|
| HK IHV 1.0 REPKIT | HK IHV 1.0 ltr | Bladder 1.0 litre NBR, Ø22 mm 7/8"-14UNF | 0,5 |
| HK IHV 1.6 REPKIT | HK IHV 1,6 ltr | Bladder 1.6 litre NBR, Ø16 mm 5/8"-14UNF | 0,6 |
| HK IHV 2.5 REPKIT | HK IHV 2.5 ltr | Bladder 2.5 litre NBR, Ø22 mm 7/8"-14UNF | 0,7 |
| HK IHV 4.0 REPKIT | HK IHV 4.0 ltr | Bladder 4.0 litre NBR, Ø22 mm 7/8"-14UNF | 1,0 |
| HK IHV 5.0 REPKIT | HK IHV 5.0 ltr | Bladder 5.0 litre NBR, Ø22 mm 7/8"-14UNF | 1,2 |
| HK IHV 6.0 REPKIT | HK IHV 6.0 ltr | Bladder 6.0 litre NBR, Ø22 mm 7/8"-14UNF | 1,5 |
| HK IHV 10.0 REPKIT | HK IHV 10.0 ltr | Bladder 10.0 litre NBR, Ø22 mm 7/8"-14UNF | 1,5 |
| HK IHV 10K2 REPKIT | HK IHV 10.0 ltr K2 | Bladder 10.0 litre K2 NBR, Ø22 mm 7/8"-14UNF | 1,7 |
| HK IHV 12.0 REPKIT | HK IHV 12.0 ltr | Bladder 12.0 litre NBR, Ø22 mm 7/8"-14UNF | 2,0 |
| HK IHV 20.0 REPKIT | HK IHV 20.0 ltr | Bladder 20.0 litre NBR, Ø22 mm 7/8"-14UNF | 2,3 |

Spare part for following products

HK IHV Bladder accumulator