


# HK IHV REPKIT

Repair kit for bladder accumulator



## Note

Repairs to pressure accumulators may only be carried out by qualified personnel! Please observe the repair instructions supplied.

## Description

For IHV bladder accumulators

Consisting of replacement bladder, seal kit and split ring

## Item

Identification	for bladder accumulator	Replacement bladder	Weight (kg)
HK IHV 1.0 REPKIT	HK IHV 1.0 ltr	Bladder 1.0 litre NBR, Ø22 mm 7/8"-14UNF	0,5
HK IHV 1.6 REPKIT	HK IHV 1,6 ltr	Bladder 1.6 litre NBR, Ø16 mm 5/8"-14UNF	0,6
HK IHV 2.5 REPKIT	HK IHV 2.5 ltr	Bladder 2.5 litre NBR, Ø22 mm 7/8"-14UNF	0,7
HK IHV 4.0 REPKIT	HK IHV 4.0 ltr	Bladder 4.0 litre NBR, Ø22 mm 7/8"-14UNF	1,0
HK IHV 5.0 REPKIT	HK IHV 5.0 ltr	Bladder 5.0 litre NBR, Ø22 mm 7/8"-14UNF	1,2
HK IHV 6.0 REPKIT	HK IHV 6.0 ltr	Bladder 6.0 litre NBR, Ø22 mm 7/8"-14UNF	1,5
HK IHV 10.0 REPKIT	HK IHV 10.0 ltr	Bladder 10.0 litre NBR, Ø22 mm 7/8"-14UNF	1,5
HK IHV 10K2 REPKIT	HK IHV 10.0 ltr K2	Bladder 10.0 litre K2 NBR, Ø22 mm 7/8"-14UNF	1,7
HK IHV 12.0 REPKIT	HK IHV 12.0 ltr	Bladder 12.0 litre NBR, Ø22 mm 7/8"-14UNF	2,0
HK IHV 20.0 REPKIT	HK IHV 20.0 ltr	Bladder 20.0 litre NBR, Ø22 mm 7/8"-14UNF	2,3

## Spare part for following products

HK IHV Bladder accumulator