

# HK KM 202

Counter nut

## Properties

**Use** For control panel installation of valves HKV257 2 and HK V257 5



## Description

Installation: Release the lock of the handwheel

Loosen slotted screw under the PVC cap

Remove handwheel

Install valve using the lock nut

## Item

Identification	Thread	for valve size	Weight (kg)
HK KM 202-1/8	M 17 x 1	1/8"	0,02
HK KM 202-1/4	M 20 x 1	1/4"	0,04
HK KM 202-3/8	M 25 x 1.5	3/8"	0,06
HK KM 202-1/2	M 30 x 1.5	1/2"	0,08
HK KM 202-3/4	M 40 x 1.5	3/4"	0,10
HK KM 202-1	M 50 x 1.5	1"	0,12
HK KM 202-1 1/4	M 50 x 1.5	1.1/4"	0,14
HK KM 202-1 1/2	M 55 x 2	1.1/2"	0,16
HK KM 202-2	M 65 x 2	2"	0,18

## Accessory for following products

HK V2 572	Throttle valve
HK V2 575	Flow control check valve