

HK KM 202

Counter nut

Properties

Use For control panel installation of valves HKV257 2 and HK V257 5



Description

Installation: Release the lock of the handwheel

Loosen slotted screw under the PVC cap

Remove handwheel

Install valve using the lock nut

Item

Identification	Thread	for valve size	Weight (kg)
HK KM 202-1/8	M 17 x 1	1/8"	0,02
HK KM 202-1/4	M 20 x 1	1/4"	0,04
HK KM 202-3/8	M 25 x 1.5	3/8"	0,06
HK KM 202-1/2	M 30 x 1.5	1/2"	0,08
HK KM 202-3/4	M 40 x 1.5	3/4"	0,10
HK KM 202-1	M 50 x 1.5	1"	0,12
HK KM 202-1 1/4	M 50 x 1.5	1.1/4"	0,14
HK KM 202-1 1/2	M 55 x 2	1.1/2"	0,16
HK KM 202-2	M 65 x 2	2"	0,18

Accessory for following products

HK V2 572	Throttle valve
HK V2 575	Flow control check valve