HK KM 202
Counter nut

Properties

Use	For control panel installation of valves HKV257 2 and HK V257 5





Description

Installation: Release the lock of the handwheel
Loosen slotted screw under the PVC cap
Remove handwheel
Install valve using the lock nut

Item

Identification	Thread	for valve size	Weight (kg)
HK KM 202-1/8	M 17 x 1	1/8"	0,02
HK KM 202-1/4	M 20 x 1	1/4"	0,04
HK KM 202-3/8	M 25 x 1.5	3/8"	0,06
HK KM 202-1/2	M 30 x 1.5	1/2"	0,08
HK KM 202-3/4	M 40 x 1.5	3/4"	0,10
HK KM 202-1	M 50 x 1.5	1"	0,12
HK KM 202-11/4	M 50 x 1.5	1.1/4"	0,14
HK KM 202-11/2	M 55 x 2	1.1/2"	0,16
HK KM 202-2	M 65 x 2	2"	0,18

Accessory for following products

HK V2 572	Throttle valve
HK V2 575	Flow control check valve

Despite careful checking, we cannot guarantee the accuracy of all information included on this site, and we accept no liability.