VOM WR

Pre-assembly sockets



Propertie	es estatution estatu
Design	Pre-assembly sockets
Material	Hardened tool steel
Surface	phosphate treated





Note

The VOM WR is used for assembling the UEM WR

Item					
Identification	Series	Ød	G1	T	
VOM NW 04 HL WR	1	(mm) 6	M 12 x 1.5	(mm) 7,0	
VOM NW 06 HL WR	<u>L</u>	8	M 12 x 1.5	7,0	
VOM NW 08 HL WR	L	10	M 16 x 1.5	7,0	
VOM NW 10 HL WR	L	12	M 18 x 1.5	7,0	
VOM NW 13 HL WR	L	15	M 22 x 1.5	7,0	
VOM NW 16 HL WR	L	18	M 26 x 1.5	7,5	
VOM NW 20 HL WR	L	22	M 30 x 2	7,5	
VOM NW 25 HL WR	L	28	M 36 x 2	7,5	
VOM NW 32 HL WR	L	35	M 45 x 2	10,5	
VOM NW 40 HL WR	L	42	M 52 x 2	11,0	
VOM NW 03 HS WR	S	6	M 14 x 1.5	7.0	
VOM NW 03 HS WR	<u>S</u>	8	M 16 x 1.5	7,0	
VOM NW 04 HS WR	S	0 10	M 18 x 1.5	7,0 7,5	
				· · · · · · · · · · · · · · · · · · ·	
VOM NW 08 HS WR	S	12	M 20 x 1.5	7,5	
VOM NW 13 HS WR	S	16	M 24 x 1.5	8,5	
VOM NW 16 HS WR	S	20	M 30 x 2	10,5	
VOM NW 20 HS WR	S	25	M 36 x 2	12,0	
VOM NW 25 HS WR	S	30	M 42 x 2	13,5	
VOM NW 32 HS WR	S	38	M 52 x 2	16,0	

Series: LL = Very light L = Light S = Heavy

Accessory for following products

UEM FM WR WALRING union nut