

Properties

Use Spare for mounting via the pump plunger



Item

| Identification | Weight (kg) |
|------------------|----------------|
| HK PAM 019 01 01 | 0,1 |

Spare part for following products

| | |
|--------------|--|
| HK PAM 014 R | Manual pump for pipeline installation |
| HK PAM 014 T | Manual pump for tank installation |
| HK PAM 015 T | Manual pump for tank installation with directional control valve |