



## Description

Software for all parameters of ATOS proportional controls for monitoring and handling of current settings.

The graphical interface is constructed in layers, which represent different specific groups of functions and parameters.

The software automatically detects the connected valve type and adjusts the parameters displayed according to the selected access level.

System requirements: Windows XP or higher, 512 MB RAM, 250MB free hard disk space, DVD drive, RS232 or USB interface

## Item

Identification	Design	Weight (kg)
HK E SW BASIC	DVD with driver, software and manual	0,2
HK E SW PSN	DVD with driver, software and manual	0,2

## Accessory for following products

HK EMI	Digital electronic driver HK EMI AS IR
HK EC PC IR USB	USB infrared adapter