



**Artikel**

Aanduiding	Definitie
K- 07 30 28 69	Unloading valve
K- 07 30 28 83	Motor protection relay (overcurrent relay) 1,50 - 2,45 A
K- 07 30 28 84	Motor protection relay (overcurrent relay) 2,40 - 4,20 A
K- 07 30 28 85	Motor protection relay (overcurrent relay) 4,00 - 7,00 A
K- 07 30 28 80	Motor protection relay (overcurrent relay) 6,10 - 10,3 A
K- 07 30 28 81	Motor protection relay (overcurrent relay) 9,00 - 14,0 A
K- 07 30 28 82	Motor protection relay (overcurrent relay) 11,0 - 18,0 A
K- 07 30 28 76	Diaphragm
K- 07 30 28 73	Hood with On/Off-Switch
K- 07 30 28 72	Hood without On/Off-Switch