
# HK RV063

Valve housing for line break safety valve

## Properties

| | |
|---|---|
| **Material** | Steel |
| **Operating pressure** | max. 300 bar |






## Note

Note: Line break safety valves must be set according to the application!
Information on settings, see HK V1 601 line break safety valves

## Item

| Identification | H | M (mm) | N (mm) | O (mm) | AF (mm) | Weight (kg) |
|---|---|---|---|---|---|---|
| **HK RV063 0400** | G 1/4” | 28 | 12 | 50 | 19 | 0,07 |
| **HK RV063 0600** | G 3/8” | 31 | 13 | 58 | 24 | 0,10 |
| **HK RV063 0800** | G 1/2” | 33 | 14 | 62 | 27 | 0,17 |
| **HK RV063 1200** | G 3/4” | 40 | 16 | 75 | 32 | 0,20 |

## Accessory for following products

| | |
|---|---|
| **HK V1 601** | Line break safety valve without housing |

*Despite careful checking, we cannot guarantee the accuracy of all information included on this site, and we accept no liability.*